

New Construction 9400 CompositWood® Window Nail Fin Gasket Application Instructions

The supplied gasket is to be applied to the corners of an installed new construction 9400 window. It must be applied at all locations listed over a generous bed of recommended window sealant. This gasket will insure continuous water tight seal around the complete perimeter of the window being installed.


This process should be complete prior to final flashing of the unit.



Upon completing the window installation based on the instructions that are supplied, proceed to add the corner gaskets as directed.

A generous amount of high grade silicone must be applied into the corner of the window nail fin and along the edge of the fin at all 4 corners as shown.

Assure that the corner void is filled into the opening. Note the generous amount of silicone that will be needed for the application of the corner gasket supplied with Interstate new construction windows.



Remove backer from nail fin gasket and place gasket into sealant tight to curbing. Fully compress the gasket at all 4 corners



In the event of in-field accessory installation, make sure gasket overlaps edge of frame material as noted in photo.

For complete instructions, please visit www.interstatebdg.com/support-library "9400 New Construction Corner Gasket & Accessory Field Installation."

