

# Dust Plug Installation Instructions for Double Hung Windows

CompositWood<sup>®</sup>  
BY INTERSTATE

1. With the bottom sash tilted in and out of the way and the top sash pulled down approximately 3 inches, clean 1½” of the parting stop just below the jamb adjuster hole with alcohol wipe (included), as shown.



1.

2. Remove backer tape from dust plug and position dust plug just below the jamb adjust hole making sure the front edge of the dust plug is even with the front of the parting stop. Press to secure.



2.

3. Install plug button supplied in installation screw pack and repeat on opposite side.



3.

**INTERSTATE**  
*Window & Door Company*