

# New Construction 9400 CompositWood® Window Nail Fin Gasket Application Instructions

The supplied gasket is to be applied to the corners of an installed new construction 9400 window. It must be applied at all locations listed over a generous bed of recommended window sealant. This gasket will insure continuous water tight seal around the complete perimeter of the window being installed.

*This process should be complete prior to final flashing of the unit.*



Upon completing the window installation based on the instructions that are supplied, proceed to add the corner gaskets as directed.



Apply a generous amount of sealant at the joinery of the nail fin at all 4 corners.



Assure that the corner void is filled into the opening.



Remove backer from nail fin gasket and place gasket into sealant tight to curbing.



In the event of in-field accessory installation, make sure gasket overlaps edge of frame material as noted in photo.