



3000 North Township Blvd • Pittston, PA 18640
800-338-9997 Toll Free • 570-655-2811 Local
570-655-3242 Fax
www.interstatewindowsanddoors.com

Supplemental Astragal/Screen Installation Instructions for 4 Lite Patio Door

- Install screens per supplied screen installation. Take supplied astragal and cut to length to fit on screen between top and bottom of screen track allowing for 1/8" clearance.
- Before attaching to screen make sure the astragal has clearance along its entire travel path and will not bind along screen track.
- Check for fit and assure operation, making sure the door penetrates no less than 7/16" but no more than 1/2" into receiving pocket before applying keeper. This will ensure a proper interlock. If more penetration is required, you can remove the spacers from behind either fixed panels and push panel back into track to achieve desired depth.
- Attach astragal to the keeper side screen using the #8 x 1" pan head screws evenly distributed along length of part, as shown right.
- Note that small opening is to be applied to keeper screen. Attach screen keeper per instruction supplied with screen.

