



**SHERWIN
WILLIAMS.**

109.33

MULTI-PURPOSE
Interior Oil-Based
Primer
B49W08820

As of 02/21/2017, Complies with:			
OTC	Yes	LEED® 09 NC, CI	No
OTC Phase II	No	LEED® 09 CS	No
SCAQMD	No	LEED® 09 H	No
CARB	Yes	LEED® v4 Emissions	No
CARB SCM 2007	No	LEED® v4 VOC	No
Canada	Yes	MPI	Yes

DESCRIPTION

Multi-Purpose Oil-Based Primer is a versatile, interior, sealer and stain blocker.

- Seals out:
 - water sensitive stains
 - dried water stains
 - smoke stains and related odors
 - grease, ink, and pencil stains
- Quick drying
- Assures uniform appearance of topcoats

For use on these surfaces:

- Wood
- Hardboard
- Cured Plaster
- Paneling
- Ceiling Tiles
- Previously painted surfaces

CHARACTERISTICS

Color: White

Coverage: 350 - 400 sq ft/gal
@ 4 mils wet; 2.1 mils dry

Drying Time, @ 77°F, 50% RH:
Touch: 30 minutes
Recoat as a primer: 60 - 90 minutes
Recoat as a stain sealer: 4 hours

Drying and recoat times are temperature, humidity and film thickness dependent.

Finish: 0-5 units @ 85°

Flash Point: 90°F, PMCC

Vehicle Type: Linseed Vinyl Toluene

B49W08820

VOC (less exempt solvents):
344 g/L; 2.87 lb/gal
as per 40 CFR 59.406 and SOR/2009-264, s. 12

Volume Solids: 54 ± 2%

Weight Solids: 79 ± 2%

Weight per Gallon: 13.42 lb

WVP Perms (US) 7.6
grains/(hr ft² in Hg)

Tinting

Requires Blend-A-Color Toner for tinting. For best color development, use the recommended "P"-shade primer. If desired, up to 4 oz per gallon of Blend-A-Color Toner can be used to approximate the topcoat color. Check color before use.

When spot priming on some surfaces, a non-uniform appearance of the final coat may result, due to differences in holdout between primed and unprimed areas. To avoid this, prime the entire surface rather than spot priming.

For optimal performance, this primer must be topcoated with a latex, alkyd/oil, or waterbased epoxy on architectural applications.

SURFACE PREPARATION

WARNING! Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at **1-800-424-LEAD** (in US) or contact your local health authority.

Remove all surface contamination by washing with an appropriate cleaner, rinse thoroughly and allow to dry. Scrape and sand peeled or checked paint to a sound surface. Sand glossy surfaces dull. Recognize that any surface preparation short of total removal of the old coating may compromise the service length of the system.

Smoke, fire, or stain damaged areas- Thoroughly clean the surface before applying to smoke, fire or stained areas. After priming, allow to dry 4 hours, test a small area for bleeding by applying the topcoat before painting the entire project. If the stain bleeds through, apply a second coat of primer and allow to dry overnight and retest before topcoating. Use Multi-Purpose Latex Primer over solvent sensitive stains.



109.33

MULTI-PURPOSE
 Interior Oil-Based
 Primer
 B49W08820

<u>SURFACE PREPARATION</u>	<u>APPLICATION</u>	<u>CAUTIONS</u>
<p>Drywall Fill cracks and nail holes with patching paste/spackle and sand smooth. Joint compounds must be cured and sanded smooth. Remove all sanding dust.</p> <p>Plaster Bare plaster must be cured and hard. Textured, soft, porous, or powdery plaster should be treated with a solution of 1 pint household vinegar to 1 gallon of water. Repeat until the surface is hard, rinse with clear water and allow to dry.</p> <p>Wood Sand any exposed wood to a fresh surface. Patch all holes and imperfections with a wood filler or putty and sand smooth.</p> <p>Mildew Prior to attempting to remove mildew, it is always recommended to test any cleaner on a small, inconspicuous area prior to use. Bleach and bleaching type cleaners may damage or discolor existing paint films. Bleach alternative cleaning solutions may be advised.</p> <p>Mildew may be removed before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with water and allow the surface to dry before painting. Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. Do not add detergents or ammonia to the bleach/water solution.</p> <p>Caulking Gaps between walls, ceilings, crown moldings, and other interior trim can be filled with the appropriate caulk after priming the surface.</p>	<p>Do not reduce for stain blocking. Apply at temperatures above 50°F. No reduction needed.</p> <p>Brush Use a natural bristle brush</p> <p>Roller Use a 1/4" - 1/2" nap synthetic or mohair cover</p> <p>Spray - Airless Pressure2000 psi Tip.....015"-.017"</p> <p><u>CLEANUP INFORMATION</u> Clean spills, spatters and tools immediately after use with compliant cleanup solvent. Follow manufacturer's safety recommendations when using solvents.</p>	<p>For interior use only.</p> <p>Before using, carefully read CAUTIONS on label.</p> <p>HOTW 02/21/2017 B49W08820 17 344</p> <p>FRC</p> <p>The information and recommendations set forth in this Product Data Sheet are based upon tests conducted by or on behalf of The Sherwin-Williams Company. Such information and recommendations set forth herein are subject to change and pertain to the product offered at the time of publication. Consult your Sherwin-Williams representative or visit www.paintdocs.com to obtain the most current version of the PDS and/or an SDS.</p>